

WARRANTY

Please fill out the warranty card and mail back to the above address Please check here if you would not like to receive any solicitations from our company

Model: _____ Serial Number: _____
 NAME _____
 ADDRESS _____
 STREET _____ STATE _____ ZIP _____
 TELEPHONE _____ EMAIL _____
 DATE OF PURCHASE _____ PLACE OF PURCHASE _____

THIS UNIT COMES WITH A ONE YEAR WARRANTY SUBJECT TO THE FOLLOWING CONDITIONS:
 In the first year, all repairs will be performed free of charge or the unit will be replaced. This warranty is not transferable, it is valid only for the original purchaser. This warranty will be voided if the unit is subjected to unauthorized repair or impact damage. If you have any questions please call toll free: 877-959-1234

The Heat Innovations™ Baseboard Convection Heater With Turbo Fan comes with a 1 year manufacturer's warranty. If this unit should become defective within 1 year from the date of purchase, or if you have any questions please call Toll Free: 877-959-1234 or write to the address below.



Heat Innovations, Inc.
 2301 SW 145th Ave.
 Miramar, FL, USA 33027
www.HeatInnovations.tv

Heat Innovations™

Baseboard Convection Heater With Turbo Fan

Operation Directions

Thank you for purchasing the Heat Innovations™ Baseboard Convection Heater. This product comes with a 1 YEAR WARRANTY from the date of purchase as your satisfaction is our primary concern.

How it works?

Heat Innovations™ Baseboard Convection Heater With Turbo Fan features a unique design to help capture cold drafts from floors and windows. It helps distribute heated air into the room and is perfect for many rooms in your home or office. It is safe, quiet and portable. The fan quickly heats the air in the room and can be turned off to maintain desired temperature with ultra-quiet heating. The unit features two heat settings: 750 watts (small to medium rooms) and 1500 watts (medium to large rooms), plus fan only setting, thermostat control, and Turbo fan feature. It's slim design, heavy-duty metal cabinet and safety shut off are some of the other features included in this unit.

Directions for Usage

- Two bases are provided with the heater. Install bases prior to operating unit. (See image for how to install bases)



- Plug Unit into a grounded outlet.

- Press rocker switch to desired heat setting: (750W or 1500W). Press one rocker switch for 750W. Press down both rocker switches for 1500W.

- Turn Thermostat control knob for desired heating temperature.



- For Turbo Fan forced radiant heat, press the fan rocker switch ON.



- Once a comfortable temperature has been reached, turn the knob counterclockwise until the thermostat is OFF.



- To disconnect heater, turn controls OFF, then remove plug from outlet.

CONTROL PANEL



THERMOSTAT (ON - OFF)
HEATING VOLTAGE (750W or 1500W) (ON - OFF)
FAN (ON - OFF)

(Rocker Switches)